

DAMAGE PATROL


Quick Start Guide

Assess damaged assets from the palm of your hand




JOB LIST

The list of jobs assigned to you will appear on the **Home Screen**. Select a job to begin assessing damage.




PREEMPT A JOB

In the event that you can not complete a job assigned to you and damage has not been evaluated, please contact your manager or dispatcher. To preempt a job, select the **Hamburger Menu**, then select **Preempt Job**.



EVENT STATUS PROGRESSION


Once a job is selected, move through the event status so the dispatcher is informed on your progress. Navigate from **Acknowledge**, to **En route**, to **Arrive**, and **Patrol Complete**.



QUESTIONS

Select the **Question Marks** located throughout the app to assist with questions you may have on that page.

Event Status Progression Page



MAP

Select **Show on Map** to view features on the map. Select **Map Options** to Switch from **Normal View** to **Satellite View** to locate landmarks.


FILTER FEATURES

Filter the map by **Feature** (conductors, fuses, transformers, and poles) to view more or less features.

Use the map toggles in Map Options to view **Nearby Crews** or crews on the **Same Feeder**.

FEATURE DETAILS

View specific **Feature Info** (link, voltage, phase, feature ID, feeder ID, and coordinates) by selecting the feature on the map.



Feature Info Page

DAMAGE REPORT

Submit a Damage Report by selecting the feature on the map, and selecting **Report Damage**. Use the report form, photo upload, and additional notes field to document the damage, then select **Submit**.